

Operation Instructions



01 Keep button pressed for minimum 5 seconds to start recording. Then **RECORD LED** flashes 5 times, which indicates a successful starting. Tear off serial number label for your reference.



02 Press button once at any time to check the current status of the logger. See details of these optional features in table below.



03 Keep button pressed for minimum 5 seconds to stop recording. Then **ALARM LED** flashed 5 times which indicates a successful stopping.



04 After stopping record, tear off the transparent plastic cover and connect the logger to a USB port of the computer. The PDF and CSV report will be generated automatically and can be found in the device's folder.

Operation Indication

Start / Stop

Status	Action	LED confirmation
Start Logger	5 sec pushing button	RECORD LED flashing 5 times
Stop Logger	5 sec pushing button	ALARM LED flashing 5 times

Status Request by pushing Button 1 time

Status	Action	LED confirmation
Not Started	Push button 1 time	RECORD LED + ALARM LED flashing 1 time
Recording - OK	Push button 1 time	RECORD LED flashing 1 time
Recording - Alarm	Push button 1 time	ALARM LED flashing 1 time
Stopped - OK	Push button 1 time	RECORD LED flashing 2 times
Stopped - Alarm	Push button 1 time	ALARM LED flashing 2 times